




633F Exit Device Trim Installation Instructions

Attention Installer

Any retrofit or other field modification to a fire rated opening can potentially impact the fire rating of the opening, and Yale Locks & Hardware makes no representations or warranties concerning what such impact may be in any specific situation. When retrofitting any portion of an existing fire rated opening, or specifying and installing a new fire-rated opening, please consult with a code specialist or local code official (Authority Having Jurisdiction) to ensure compliance with all applicable codes and ratings.



Cylinder locks/
unlocks
thumbpiece.
F05 (as packed),
key removable
with trim locked
or unlocked.
F06 (field con-
version), key
removable only
when trim is
locked.

Assembly Instructions

1. Check cylinder components. Non-standard cylinder collars and mounting screws must be supplied with optional cylinders.
2. Assemble cylinder. Insert cylinder housing prongs into escutcheon matching notches. Pass cylinder tailpiece thru cylinder collar and cylinder housing slot in cam. Bolt cylinder seated in cylinder collar recess (DO NOT OVERTIGHTEN SCREWS).
3. Check cylinder action. Cylinder must freely rotate tailpiece into lock (cam pushing locking lever down) and unlock (shown) positions. When locking lever is engaged, it depresses the trim spindle. The thumbpiece handle is, thus disengaged from the spindle.
4. Cut cylinder tailpiece. Correct length is 1/16" to 3/16" (2 to 5mm) beyond cylinder housing cam.
5. Determine trim function. See **Figure 4**
F05: As shipped. Key locks/unlocks thumbpiece handle. Key removable in lock and unlock position.
F06: Field move function screw to hole in cylinder housing under cam tip. Key locks/unlocks thumbpiece handle. Key removable ONLY in lock position.





Figure 4

633F Trim

CAUTION: TO USE SCHLAGE CYLINDER YOU MUST ORDER
SCHLAGE HOUSING 60-7000-0815-000



WARNING

This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

08/2018

Installation Instructions

1. Check box for components.
 2. After marking door inside face for device location (Device Instructions), carry "Vertical Reference Centerline" from inside door face. Follow steps 2a. and 2b., shown below.
- 2a. MEASURE INSIDE LINE LOCATION.

2b. TRANSFER DIMENSION TO OUTSIDE FACE.
3. Transfer Horizontal Reference Centerline from inside to outside door face.
 4. Align trim template and tape to outside door face.
 5. Spot holes and prepare door for trim
 6. Mount trim to door thru holes "A" with (2) mounting screws as shown in Fig. 2. Use the remaining (3) oval headed screws and finish washers to secure the trim to the door surface thru location "B" as shown in Fig. 2, the third screw and washer attaches to the hole located at the bottom of the trim.
 7. With trim unlocked (tailpiece turning when thumbpiece is depressed) cut trim tailpiece as shown in Fig. 3.
 8. Seat device so that the trim tailpiece penetrates cam slot as shown in Fig. 2. Continue as shown in device instructions.




Figure 2





Figure 3


NOTE : Measure from device mounting surface (door face or shim surface).
* Trim must be in un-locked position.

*** - Double Cylinder Housing Assembly
Supplied with Exit Device



633F Trim Template

**DOOR
OUTSIDE FACE**



CAUTION: Office copiers and facsimile machines may change the size of a drawing and make the template inaccurate to use as a door marker. If this is not the original template packed with the trim, use only the holes on the door (do not use template as a door marker).

Dimensions given in inches (mm).

Yale Locks & Hardware

Product Support Tel 800.438.1951 • Fax 800.338.0965 • www.yalelocks.com

Yale® is a registered trademark of Yale Security Inc., an ASSA ABLLOY Group company. Other products' brand names may be trademarks or registered trademarks of their respective owners and are mentioned for reference purposes only. These materials are protected under U.S. copyright laws. All contents current at time of publication. Yale Security Inc. reserves the right to change availability of any item, its design, construction, and/or its materials. Copyright © 2005, 2013, Yale Security Inc., an ASSA ABLLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Yale Security Inc. is prohibited.

80-8470-0633-000 (1-1-18)
ASSA ABLLOY

An ASSA ABLLOY Group brand